

BrightBio® LOIMU-K35 BIOPLASTIC

TECHNICAL DATA SHEET



PRODUCT DESCRIPTION

BrightBio® LOIMU-K35 is a biobased polyester which is modified for improved impact properties. LOIMU-K35 biomaterial is designed to fit cold conditions as it preserves mechanical performance even in sub-zero temperatures.

Applications:	Consumer products, containers, etc.
Processing methods:	Injection moulding
Technical benefits:	Impact properties, toughness in cold conditions
Environmental benefits:	Biobased content is 65 %

PHYSICAL PROPERTIES	VALUE	UNIT	STANDARD
Density	1.2	g/cm ³	ISO 1183
Melt Flow Rate 190 °C/2.16 kg	16-21	g/10 min	ISO 1133
MECHANICAL PROPERTIES	VALUE	UNIT	STANDARD
Tensile Strength, 23 °C	38	MPa	ISO 527
Tensile Strain at Break, 23 °C	> 300	%	ISO 527
Tensile Modulus, 23 °C	2900	MPa	ISO 527
Tensile Stress at Yield, 23 °C	38	MPa	ISO 527
Tensile Strain at Yield, 23 °C	2.4	%	ISO 527
Charpy Impact Strength Notched, 23 °C	11	kJ/m ²	ISO 179
Charpy Impact Strength Notched, - 20 °C	7	kJ/m ²	ISO 179
THERMAL PROPERTIES	VALUE	UNIT	STANDARD
Heat Deflection Temperature, Method A, 1.8 MPa	54	°C	ISO 75
Vicat softening point, 10 N, 50 °C / h	59	°C	ISO 306

BrightBio® LOIMU-K35 BIOPLASTIC

PROCESSING ADVICE



PROCESSING CONDITIONS FOR INJECTION MOULDING¹

SHRINKAGE	VALUE	UNIT
Linear Mould Shrinkage	0.4	%

PRE-DRYING	VALUE	UNIT
Pre-drying Temperature	40 - 60	°C
Pre-drying Time ²	12 - 24	h

PROCESSING TEMPERATURES	VALUE	UNIT
Feeding zone	25 - 30	°C
Zone 1	170 - 175	°C
Zone 2	175 - 190	°C
Zone 3	185 - 200	°C
Nozzle	190 - 205	°C
Mould Temperature	35 - 40	°C

PROCESSING PARAMETERS	VALUE	UNIT
Screw Speed	Low-Medium	rpm
Injection Speed	Medium	rpm
Back Pressure	0.6 - 1	MPa
Holding Pressure (half of injection pressure)	50	%

¹These general guidelines are only to use as reference. Exact settings must follow the product and machine conditions. ²Pre-drying to < 0.025% moisture content is recommended to avoid property losses.

BrightBio® LOIMU-K35 BIOPLASTIC

PROCESSING ADVICE



MACHINE CLEANING

After processing BrightBio® LOIMU-K35, the machinery should be purged with polypropylene to clean the machinery. For further technical information, please contact our tech support, support@brightplus.com, with your specific processing requirements.

STORAGE, DRYING AND HANDLING

It is recommended to store BrightBio® LOIMU-K35 in its closed, original packaging in a normal room temperature. Storage in direct sunlight and in humid conditions should be avoided. It is recommended to dry BrightBio® LOIMU-K35 carefully before processing. Please notice, that a very long drying time in combination with high temperature may cause degradation and agglomeration of pellets.

PRODUCT SAFETY

Please, refer to the material safety datasheet (MSDS) of BrightBio® LOIMU-K35 for detailed information.

DISCLAIMER

The information in this Data Sheet is given according to our best knowledge at the date shown in footer. These are only typical values and actual product specification may deviate at industrial range. The information is guidance for safe handling, use, processing, and storage. The customer himself is required to verify whether the product is suitable for the further processing or application intended and whether the product complies with the relevant statutory requirements. This data sheet is for informative purpose only and all specifications need to be discussed and agreed with Brightplus Oy separately.